







1





2





3





4





5





6





7





8





9





10





11





12





13





14





15





16





17








19





2x

2x

This inset box shows the parts required for step 20. At the top is a 1x4 black Technic brick with four holes. Below it is a 1x6 black Technic axle with a bush on one end and a hole on the other. At the bottom is a 1x6 black Technic axle with a bush on one end and a hole on the other. The quantity '2x' is written next to each part.

